

Echo Measurement Utility (EMU)



818 West Diamond Avenue - Third Floor, Gaithersburg, MD 20878
Phone: (301) 670-4784 Fax: (301) 670-9187 Email: info@gl.com
Website: <https://www.gl.com>

Basic Concept




- GL's Echo Measurement Utility (EMU) software is an offline adjunct analysis application (under control of VQuad™) that compares the source and received files to determine echoes and delay of echoes
- EMU software assess sidetone, line, and acoustic echo and the corresponding delays

Features

- Detect Acoustic/Line (Hybrid) echoes and evaluate intermittent echoes
- Echo, Delay, and Voice Quality Analysis of Voice Calls in VoIP, TDM, 2Wire, and Mobile Networks
- Measures EPD in msec and ERL in dB
- Compares source and received files to detect echo (maximum of four instances)
- Supports Auto Method and Manual Method of operation
- Ability to automate the entire test process using VQuad™ scripting; including sending the results to the central database for access via GL's WebViewer™
- EMU uses EMU Client software to automatically detect the incoming degraded voice files and send the measurements to database after analysis
- Graphically displays source signal, received signal, error signal, and adaptive filter coefficients
- Calculates adaptive filter coefficients and echo characteristics for the error signal

User Interface



- Provides Delay and ERL measurements for all detected echoes, along with an 'ERL vs Delay' plot
- Includes signal graphs for source signal, received signal, error signal, and adaptive filter coefficients

Measurement Parameters




The screenshot shows a 'Settings' dialog box with a 'File' menu and a 'Settings' section. A warning message reads: 'Warning: Please read the userguide, Before changing the parameters'. The settings are organized into two columns:

Parameter	Value	Unit
Filter Coefficients Length	2	sec
Step Size of Filter	0.03	
Double talk Detector Threshold	0	dB
Double talk Detector Hangover Time	80	msec
Echo power window length	0.5	sec
Single talk Threshold	-35	dBm
ERL Threshold (yes / no)	-60	dBm
Minimum single talk length	3	sec
Maximum single talk length	10	sec
Sampling Rate	8000	Hz

At the bottom right, there are two radio buttons: 'Manual Method' (unselected) and 'Auto Method' (selected). An 'Apply' button is located at the bottom center.


- Customizable parameters to control the EMU input and output includes - Filter Coefficients Length, Step Size, Double talk Detector Threshold, Double talk Detector Hangover Time, Echo power window length, Single talk Threshold, ERL threshold, Minimum Single talk length, Maximum Single talk length and Sampling rate

Auto Method




- The input files are analyzed and the echo characteristics are given as blocks (Blocks are divided based on time duration of input files and parameter settings)

Manual Method



- After analyzing the input files, the users have to manually select a region of Input / Output stereo signal plot to obtain the echo characteristics results

Detailed Analysis




- Displays received signal (in dBm format), error signal (in seconds), calculates adaptive filter coefficients and provides up to 4 echo characteristics

Results

Echo Measurement Results

OPERATOR INFORMATION		
Name	User's Name	
JOB Title	Test Engineer	
JOB ID	21-Jan-2011 and Run # Line Echo Mode	
User Note	2 wire to mobile measurements	
FILE INFORMATION		
Intrusive File	E:\Program Files\GL Communications Inc\Echo Measurement Tool\Intrusive_files\Acoustic_fem_10sec.pcm	
Received File	E:\Program Files\GL Communications Inc\Echo Measurement Tool\Received_files\Examples\2wire to mobile\2w_mob_fem.PCM	
Error	Error display	
Filtercoef	Filtercoef display	
ERL VS De	ERL VS Delay plot	
ECHO CHARACTERISTICS		
Total no of Attenuati	Delay(ms)	
Echo1	-21	26.25
Echo2		
Echo3		
Echo4		

Delay vs ERL Results




- Generated “Result” spread sheet includes operator information, file information, echo characteristics, and snapshots of all the signal graphs

Testing Scenarios

- EMU in Line (Hybrid) Echo Mode of Operation
 - Two wire – Two wire Setup
 - Two wire – Mobile Setup
 - Two wire (direct to gateway) to VoIP Phone Setup
 - Two wire (through T1 E1 Switch) to VoIP phone setup
 - Two wire (through T1 E1 Switch) to VQuad™ software (Ethernet Interface) Setup
 - Two wire (direct to gateway) to VQuad™ software (Ethernet Interface) Setup
 - Mobile phone to Mobile phone Setup
 - Mobile phone to VoIP phone Setup
 - VQuad™ (Ethernet Interface) to IP PBX to two-wire Setup
 - VoIP phone to IP PBX to Two-wire Setup
- EMU in Acoustic Echo Mode of Operation


Two wire – Two wire Setup

EMU in Line (Hybrid) Mode of Operation




- As depicted in the above picture, a call is placed from one port of RJ11 to other port of RJ11 through an outside Central Office due to hybrid circuitry in the overall path, echo exists as side-tone and line (hybrid) echo

Two-Wire – Mobile Setup




- Call is placed from one port of RJ11 to a mobile where the connection path is shown above. Echo cancellers exist in the two-wire to mobile path between central office to base station
- Intrusive file sent from Port of RJ11 (2-wire) to mobile - The one echo, which can be seen in this setup, is the side-tone as shown at 2-wire connection
- Intrusive file sent from mobile to Port of RJ11 (2-wire) - There will be no side tone with mobile connection, but there could be line (hybrid) echo depending on the EC performance / existence

Two-Wire (Direct to Gateway) -VoIP Phone Setup




- Call is placed from one port of RJ11 to VoIP phone through the gateway and Ethernet network. Based on the configuration of echo canceller (EC) in the gateway, which can be enabled or disabled, echo exists at the VoIP phone. At the PC / Dual UTA there will be side-tone
- Intrusive file sent from Port of RJ11 (2-wire) to VoIP phone - The one echo, which can be seen in this setup with Echo Canceller setting enabled, is the side-tone as shown at 2-wire connection

Two-Wire (through T1 E1 Switch) to VoIP Hybrid Echo Measurement



- Call is placed from one port of RJ11 to VoIP phone through the Class 5 T1 E1 Switch, Gateway and Ethernet network
- Echo cancellers exist in the two-wire to VoIP phone path as part of the gateway. The one echo, which can be seen in this setup, is the side-tone at the PC / Dual UTA. The VoIP phone may experience echo depending on the EC performance


Two-Wire (through T1 E1 Switch) to VQuad™ Software (Ethernet Interface) Setup



- Call is placed from one port of RJ11 to Ethernet interface of VQuad™ software through the T1 E1 Switch, Gateway and Ethernet network. Echo cancellers exist in the two-wire to Ethernet interface of VQuad™ software path between T1 E1 Switch
- The one echo, which can be seen in this setup, is the side-tone. On the VoIP side, there may be echo based on the performance of the EC

Two-Wire (Direct to Gateway) to VQuad™ Software (Ethernet Interface) Setup


EMU in Line (Hybrid) Mode of Operation



- Call is placed from one port of RJ11 to Ethernet interface of VQuad™ software through the gateway and Ethernet network
- Echo canceller exists in the overall path in Ethernet interface and in gateway based on the configuration. Side-tone exists at the 2Wire and may exist at the VoIP connection depending on the performance of the EC


Mobile Phone to Mobile Phone Setup

EMU in Line (Hybrid) Mode of Operation



- Call is placed from near-end mobile phone (4 – wire analog) to far-end mobile phone (4 – wire analog). Generally, there are no ECs in mobile-to-mobile connections
- There are no side-tone also as mobile is connected in headset mode

Mobile Phone to VoIP Phone Setup




Call is placed from near-end mobile phone (4 – wire analog) to Ethernet interface of the other port via VoIP phone or vice versa.

- Intrusive file sent from Mobile to VoIP phone or VQuad™ (Ethernet Interface) - Echo cancellers exist in the mobile network. There is no side-tone as mobile is connected in headset mode
- Intrusive file sent from VoIP phone or VQuad™ (Ethernet Interface) to Mobile - Echo cancellers exist in overall path. The one echo, which can be seen in this setup, is the side-tone at the VoIP phone

VQuad™ (Ethernet Interface) to IP PBX to Two-Wire Setup

EMU in Line (Hybrid) Mode of Operation




Call is placed from one port of RJ11 to Ethernet interface of VQuad™ software through IP PBX exchange, Ethernet network or vice-versa.

- Intrusive file sent from VQuad™ (Ethernet Interface) to Port of RJ11 (2-wire) - Echo cancellers exist in overall path; there is no side-tone across VQuad™ (Ethernet Interface), but there could be echo based on performance of EC


VoIP Phone to IP PBX to Two-Wire Setup

EMU in Line (Hybrid) Mode of Operation



- Call is placed from one port of RJ11 to VoIP phone through IP PBX exchange, Ethernet network or vice-versa
- Intrusive file sent from VoIP phone to RJ11 (2-wire) port - Echo cancellers exist in overall path
- The one echo, which can be seen in this setup, is the side-tone as shown across the VoIP phone

EMU in Acoustic Echo Mode of Operation



- Call is being generated from RTP ToolBox™ (or VQuad™ VoIP SIP Soft phone) of computer 1 to computer 2. The configuration at computer 2 is such that the file received at computer 2 is played to the speaker and the audio is sent back to source using the microphone
- The intrusive and the received files at computer 1 are compared for echo measurement
- The path of acoustic echo is depicted in dotted lines, which is the leak between the speaker and mic of computer 2


EMU with GL Tools

The EMU requires only two files to function – the 'sent' file and simultaneously recorded 'received' file. Any tool that achieves this can be used with EMU. GL offers various emulation and capture tools that are compatible with the EMU:

- For VoIP: VQuad™ or RTP Toolbox™
- For Mobile Phones: VQuad™ with Dual UTA HD
- For TDM: VQuad™ with USB T1 E1 unit, or tProbe™ T1 E1 unit alone, or USB T1 E1 unit alone, Universal T1 E1 Card alone
- For 2Wire: VQuad™ with Dual UTA
- For 4Wire: VQuad™ with Dual UTA

EMU with VQuad™ and Dual UTA HD

EMU with VQuad™ software




EMU with VQuad™ software

- VQuad™ software along with the Dual UTA HD hardware supports transmitting and receiving files across the following interfaces:
RJ11 2-wire analog, 3.5 mm jack for mobile headset connection, Handset phones and balanced I/O for VoIP soft phones


EMU with GL's Intrusive RTP ToolBox™ Tool

EMU with RTP Toolbox™ Tool




- GL's RTP Toolbox™ or VQuad™ with VoIP option can be used with EMU to assess line or acoustic echo

EMU with GL's Intrusive T1 E1 Analyzers




- GL's T1 E1 Analysis application (requires hardware) is used with EMU to detect possible echoes through a T1 E1 channel
- Through T1 E1 WCS scripting or VQuad™ with T1 E1 option it is possible to automate the entire testing process including sending and receiving files
- The intrusive files and the received files are fed as input to EMU for further analysis

EMU Client



- EMU Client automatically initiates the Echo measurements on arrival of degraded voice files
- It remotely connects to Central Database and sends the EMU results, which is then observed in VQT WebViewer™

EMU Results in WebViewer™


GL Communications Inc.
Telecommunication Products and Consulting
VQuad WebViewer - Real Time Monitoring System, Version 2.

Results
Call Events
Statistics/Status
Filters
Output Results
Configuration
Logout

Load Filter ON OFF

Time Filter

Timestamp Search

Auto refresh

Records Per Page

EMU Results

VQuad Timestamp	Call Timestamp	VQuad Location	VQuad PhoneID	VQuad Lat/Long	Echo1 ERL (dB)	Echo1 Delay (ms)	Echo2 ERL (dB)	Echo2 Delay (ms)	Echo3 ERL (dB)	Echo3 Delay (ms)	Echo4 ERL (dB)	Echo4 Delay (ms)	Call Control Event	VQuad CallID
04/20/2012 13:38:22	03/17/2011 15:01:56	FXOTOFXO	F2	0000000000 000000000000	0.00	24.88							EMUResult	I_FXOTOFXO_F2_20110317150
04/20/2012 13:38:06	03/17/2011 14:45:46	FXOTOFXO	F1	0000000000 000000000000	-22.00	87.13	-21.00	201.13	-15.00	300.38	-21.00	495.63	EMUResult	O_FXOTOFXO_F1_2011031714
04/20/2012 13:37:35	03/17/2011 14:43:09	FXOTOFXO	F2	N39°08'35" W077°12'57"	-21.00	5.38	-19.00	44.13	-22.00	75.00	-18.00	80.75	EMUResult	I_FXOTOFXO_F2_20110317144
04/20/2012 12:33:54	03/17/2011 15:01:56	FXOTOFXO	F2	0000000000 000000000000	0.00	24.88							EMUResult	I_FXOTOFXO_F2_20110317150
04/20/2012 12:33:38	03/17/2011 14:45:46	FXOTOFXO	F1	0000000000 000000000000	-22.00	87.13	-21.00	201.13	-15.00	300.38	-21.00	495.63	EMUResult	O_FXOTOFXO_F1_2011031714
04/20/2012 12:33:07	03/17/2011 14:43:09	FXOTOFXO	F2	N39°08'35" W077°12'57"	-21.00	5.38	-19.00	44.13	-22.00	75.00	-18.00	80.75	EMUResult	I_FXOTOFXO_F2_20110317144
04/20/2012 12:32:38	03/16/2011 14:27:34	FXOTOFXO	F2	0000000000 000000000000	-3.00	0.38	-12.00	3.25	-13.00	11.63	-26.00	29.88	EMUResult	I_FXOTOFXO_F2_20110316142
06/27/2011 16:26:32	03/17/2011 14:43:09	FXOTOFXO	F2	N39°08'35" W077°12'57"	-3.00	0.38	-12.00	3.25	-13.00	11.63	-26.00	29.88	EMUResult	I_FXOTOFXO_F2_20110317144
06/27/2011 16:17:17	03/16/2011 14:27:34	FXOTOFXO	F2	0000000000 000000000000	-21.00	5.38	-19.00	44.13	-22.00	75.00	-18.00	80.75	EMUResult	I_FXOTOFXO_F2_20110316142

EMU and Other Related Products

EMU037	Echo Measurement Utility (EMU) Software
VQT010	VQuad™ Software (Stand Alone)
VQT241	Dual Universal Telephony Adapter (UTA) with RTD, and OWD
VQT013	VQuad™ with SIP (VoIP) Call Control
VQT015	VQuad™ with T1 E1 Call Control
PKB081	Automated Acoustic Echo Cancellation (AEC) Compliance Test Software
PKB100	RTP ToolBox™
PKB080	Auto EC Test TDM-VoIP G.168 Test Software
VQT030	Network Command Center (Multi-Node Command and Control Center for VQuad™ Systems)

Thank you